


Guida per l'utente

Introduzione

È possibile associare il telecomando con un solo Apple TV alla volta. Quando si associa un telecomando, viene automaticamente annullata l'associazione precedente di qualsiasi telecomando.


Questo telecomando funziona solo con Apple TV HD o Apple TV 4K.

1. **IMPORTANTE:** aggiornare Apple TV alla versione tvOS 14.3 o successiva.
2. Rimuovere la linguetta di estrazione della batteria.




3. Spostare il telecomando entro 8 - 10 cm (3 - 4 pollici) da Apple TV.
4. Premere qualsiasi pulsante.
5. Se Apple TV non risponde, tenere premuto **MENU** ed **+** per 5 secondi per impostare il telecomando in modalità di associazione.

Una volta associato il telecomando, viene visualizzato un messaggio su Apple TV.














Non tutte le funzioni sono disponibili in tutte le aree.

Per utilizzare i pulsanti di navigazione:

- Premere i pulsanti Sinistra, Destra, Su o Giù per navigare nei menu Apple TV.
- Premere il pulsante centrale per selezionare una voce di menu o tenere premuto per accedere a un menu contestuale.
- Durante la riproduzione, eseguire una delle seguenti operazioni:
 - Premere il pulsante Sinistra per tornare indietro o premere il pulsante Destra per andare avanti.
 - Premere il pulsante Sinistra e tenere premuto per tornare indietro o premere il pulsante Destra e tenere premuto per avanzare velocemente.
 - Premere Seleziona o  per riprendere la riproduzione.

Per utilizzare i pulsanti del telecomando:

- Premere  per attivare Apple TV. Tenere premuto per mettere in stand-by Apple TV.
- Tenere premuto  per attivare Siri. Tenere premuto il pulsante Siri fino a quando non si finisce di parlare.
- Premere  o  per cambiare canale mentre si guardano i canali del proprio fornitore TV o per spostare una pagina su o giù nella guida alla programmazione.
- Premere **GUIDE** per accedere alla guida ai programmi del proprio fornitore TV.
- Premere  o  per regolare il volume del televisore o del sistema home theater.
- Premere  per disattivare l'audio. Premere di nuovo per riattivarlo.
- Premere **MENU** per tornare al menu precedente. Tenere premuto per tornare alla schermata iniziale.
- Premere  per passare a TV/Schermata iniziale.
 - Premere due volte velocemente per visualizzare le app aperte. Per chiudere un'app, navigare a sinistra o a destra nell'app, quindi premere SU due volte velocemente.
 - Tenere premuto per accedere al Centro di controllo.
- Premere  per riprodurre o mettere in pausa una trasmissione televisiva, un filmato, una canzone o una presentazione.
- Premere  o  per tornare indietro o avanzare velocemente 2x/4x/8x oppure tenere premuto per effettuare la ricerca durante la riproduzione dei contenuti.

Per saperne di più

La guida per l'utente di Apple TV contiene informazioni complete e aggiornate sul prodotto.

Accedere al sito Web all'indirizzo help.apple.com/appletv.

Per assistenza, rivolgersi al proprio fornitore TV o accedere al sito Web all'indirizzo www.apple.com/support/appletv.

Regulatory compliance information

FCC Compliance Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment has been verified to comply with the limits for a Class B computing device, pursuant to FCC Rules. The user is cautioned that changes and modifications made to the equipment without the approval of manufacturer could void the user's authority to operate this equipment.

FCC Authorization Label

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

IFETEL y NOM

La operación de este equipo está sujeta a las siguientes dos condiciones: (1) es posible que este equipo o dispositivo no cause interferencia perjudicial y (2) este equipo o dispositivo debe aceptar cualquier interferencia, incluyendo la que pueda causar su operación no deseada.

For Industry Canada

Industry Canada Statement

This device complies with RSS- 210 of the Industry Canada Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Pour les Industries au Canada

Énoncé des Industries au Canada

Cet appareil est conforme à la norme RSS-210 des règles des Industries au Canada. Son fonctionnement est soumis aux deux conditions suivantes: (1) cet appareil ne doit pas causer d'interférences nuisibles, et (2) cet appareil doit accepter toute interférence reçue, y compris les interférences pouvant causer un fonctionnement indésirable.

Caution

Please read all safety instructions to ensure personal safety and prevent damage to equipment.

Warning

- Do not place remote control in fire or near a source of heat.
- Keep the battery and/or the remote control away from direct sunlight, moist or any source of heat.
- Do not disassemble the remote control.
- Risk of explosion if any of the batteries are replaced by an incorrect type. Always use new batteries for replacement.
- Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery can result in an explosion.
- Do not leave the battery in an extreme environment such as high temperature or low air pressure. This may result to explosion or leakage of hazardous substances.

Important

Read and follow all instructions.

Declaration of Conformity

Hereby, Universal Electronics Inc. declares that the radio equipment type UEI - R39000 and Unity is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address:

www.urcsupport.com/urc_product/apple-remote/.

Product Disposal (European Directive 2012/19/EU)



The crossed-out wheeled bin symbol on this product ensures that this product is manufactured using high quality components that can be recycled and reused according European Directive 2012/19/EU.

Please do not dispose of this product with your normal household waste, refer to local regulations for the proper collection or disposal of electrical and electronic products. This will help in preventing negative effects on the environment and/or human health.



